



# B.M.R. MFG. INC.

Box 657, 673 County Rd. #38  
Campbellford, ON K0L 1L0

Telephone: 1-705-653-4111  
Fax: 1-705-653-4454



**TOLL FREE 1-800-461-7660**

Jim Reavell - jimreavell@bmr-mfg.ca Web page - www.bmr-mfg.ca

## BMR600: PULSE/STROBE LED STOP ARM KIT

Thanks for choosing BMR super bright LED stop arm lamps. Industry application: OEM and Retro-fit for replacement of incandescent warning lamps. Resulting in superior warning to the motoring public and ultimately to the safety of our children.

Lamp Kit includes as follows.

1. (2) Rear mount LED Lamps, with protected tubing and gaskets.
2. (2) Front mount LED Lamps with gaskets and connector to rear lamps.
3. 8 lamp mounting screws rear lamp side.
4. Mounting hardware, rivets, and clips.

Step 1 retro-fit:

**A: Remove existing Stop Arm Lamps. Leave lamp wires uncut until new LED lamps are installed. Lamps wires can be spliced or the preferred connection would be to pull the new LED lamps wires into the bus.**

**B: Install LED lamp kit with Stop Arm in the open position. See illustration for guidance. Rear lamps have harness to be fastened to back side of the sign blade. Use fasteners as illustrated and supplied.**

**C: Connect LED lamp wires. WARNING: +12volt only or BMR9024F 24volt Module. BLACK to (-) secure ground. RED to (+12) for pulse flash mode  
Or  
WHITE to (+12) for strobe flash mode.**

