



B.M.R. MFG. INC.



Box 657, 673 County Rd. #38
Campbellford, ON K0L 1L0

Telephone: 1-705-653-4111
Fax: 1-705-653-4454

TOLL FREE 1-800-461-7660

www.bmr-mfg.ca

BMR9011L CONTROL MODULE CONNECTION INSTRUCTIONS

For Crossing Gate with Permanent Magnetic Lock



MTR+	-Red Wire from motor
MTR-	-Black Ground Wire from motor
+12V	-Red vehicle +12 volts
GND	-Green vehicle ground
Door 12V or Trigger	-Yellow +12 volts
Inhibit	-White Wire—Optional Momentary
or	Ground Switch Kit
Lock	-White wire controls lock



B.M.R. MFG. INC.



Box 657, 673 County Rd. #38
Campbellford, ON K0L 1L0

Telephone: 1-705-653-4111
Fax: 1-705-653-4454

TOLL FREE 1-800-461-7660

www.bmr-mfg.ca

BMR9011L CONTROL MODULE CONNECTION INSTRUCTIONS

For Crossing Gate with Permanent Magnetic Lock



MTR+	-Red Wire from motor
MTR-	-Black Ground Wire from motor
+12V	-Red vehicle +12 volts
GND	-Green vehicle ground
Door 12V or Trigger	-Yellow +12 volts
Inhibit	-White Wire—Optional Momentary
or	Ground Switch Kit
Lock	-White wire controls lock